



**GERBER®**

**INSTRUCTIONS FOR MOUNTING  
No. 13-743 LAVATORY ★**

1. MARK CENTER LINES FOR LOCATION OF LAVATORY IN SLAB OR COUNTER TOP.
  2. CUT OUT TEMPLATE AND WITH CENTER LINE ARROWS AS A GUIDE, TRACE LINE ON COUNTER TOP.
  3. CUT OPENING IN COUNTER TOP CAREFULLY, FOLLOWING PENCIL LINE YOU TRACED.
  4. MOUNT LAVATORY TO UNDERSIDE OF COUNTER TOP, ALIGNING WITH CENTERLINE OF FAUCET DRILLING. GERBER ANCHOR KIT #99-190 IS AVAILABLE TO SUPPORT THIS MOUNTING.
  5. CHECK DIMENSIONS OF INTENDED FAUCET BEFORE DRILLING.
- ★ NOTE: DUE TO SLIGHT DIMENSIONAL VARIATIONS WE RECOMMEND USING LAVATORY AS A TEMPLATE TO INSURE PROPER ALIGNMENT OF UNDERCOUNTER INSTALLATION.

BROKEN LINE REPRESENTS  
LAVATORY RIM WHEN SET

CUT OUT COUNTERTOP ALONG SOLID LINE

